

INSTALLATION GUIDE:

SpringBond FR is a heavy contract rated double-stick underlay system, approved by the following leading adhesives companies:

ARDEX

T: 01440 714939

www.ardex.co.uk

F. BALL

T: 01538 361633

www.f-ball.co.uk

MAPEI

T: 0121 5086970

www.mapei.co.uk

UZIN

T: 01788 530080

www.uk.uzin.com

SpringBond FR has been tested by each of the recommended adhesive manufacturers and the following recommended adhesives list has been compiled based on their approvals.

Substrates should always be sound, dry, smooth and free from dirt, oil and grease. Should the substrate require surface preparation, please refer to the relevant recommended adhesive manufacturer for their advice and recommendations on suitable primers and levelling compounds.

Installation of SpringBond FR should be in accordance with the British Standard Code of Practice BS5325 and should be undertaken by experienced fitters.

RECOMMENDED ADHESIVES:

	SUBSTRATE TACKIFIER	CARPET ADHESIVE
ARDEX	Ardex AF 825	Ardex AF 325
F BALL	Styccobond F40	Styccobond F3
MAPEI	Ultrabond Eco Fix	Ultrabond Eco TX 2
UZIN	UZIN Universal Tackifier	UZIN KE 2560

Note: Application of the recommended adhesives must be in accordance with the adhesive manufacturers' instructions, which may include the use of a primer on absorbent surfaces.

APPLICATION METHOD:



1. Apply surface tackifier using a recommended roller or notched trowel, all in accordance with the adhesive manufacturer's instructions and allow to dry to a transparent film.



2. Once the tackifier is dry, roll out Spring Bond FR with printed side up. Ensure that the seams are closely butted and run at 90 degrees to the seams in the carpet.



3. Tape underlay joints using Texfelt Joining Tape, or other approved carpet underlay joining tape.



4. Apply the adhesive with a notched trowel, as recommended by the adhesive manufacturer.



5. Lay the carpet onto the adhesive, observing the adhesive's 'airing' and 'working' times. Remove any air pockets and ensure good adhesive transfer using a carpet glider and/or roller.

Note: The use of too heavy a roller, may stretch the carpet backing and displace the adhesive.

Note: Allow the carpet adhesive to set, usually for a minimum of 24 hours (as per the adhesive manufacturer's recommendation), before exposing to foot traffic.



Texfelt
Underlay & Fibre Technology

Unit 2, Cutler Heights Business Park, Cutler Heights Lane, Bradford, BD4 9AW, UK.

T: +44 (0) 1274 905411 E: info@textfelt.co.uk W: www.textfelt.co.uk